


1 Multimedia Functions

For multimedia functions press FN & relevant key (as listed below)

- F1 Open default media player program
- F2 Decrease system volume
- F3 Increase system volume
- F4 Mute system volume
- F5 Play previous media track
- F6 Play next media track
- F7 Play or pause current media track
- F8 Stop current media track
- F9 Open home page
- F10 Open default e-mail program (Not web-mail)
- F11 Open My Computer
- F12 Open My favorite



Led Control keys

- 2 Turn on / Turn off the LED backlight
- 3 FN+(1-9) Switch in 9 LED mode, FN+1 defaulted one. FN+7, can customize 6 district backlight color. Press FN + 7 twice, white color flashes. Press FN+Up/Down to choose current district color; FN+ Left/Right to change the district; customized color can be saved when power off. FN+9, sounds control backlight; the brightness changes according to the voice detected. FN+9 one time, the LED changes in 7 colors. Press FN+9 twice, the LED in Red color
- 4 FN & Pg Up Increases the Brightness
FN & Pg Dn Decreases the Brightness
- 5 FN & + Make the backlight breathing speed faster
FN & - Make the backlight breathing speed slower

Specifications:

Connectivity: USB
 Dimensions: (L) 470 x (W) 190 x (H) 35mm
 Net Weight: 700 ± 50g
 Key Quantity: 104
 Multimedia Keys: 12 (F1-F12 with FN Key)
 OS Support: Windows 2000 / XP / ME / Vista / 7 / 8 / 10 / Android / Linux / Mac OSX

Key Travel: 5.5mm
 Key Force: 55g±7g
 Power: +5V DC 300mA
 M.T.B.F.: 10 Million Keystrokes
 Cable Length: 1.75m
 Colour: Black

Gaming function keys



Press 'FN' key and 'W' key to swap the cursor keys and 'W,A,S,D' keys for game play.



Press 'FN' key and 'Windows' key to enable or disable 'Windows' key (Winlock)



Press FN+ PRTSC to start Macro recording function, enter requested key combinations, enter requested macro key (G1-G3), to save the recording. Press FN + PRTSC and requested macro key to cancel the recording.

9 Multi-key anti-ghosting

Your commands and simultaneous keystrokes register the way you intended. Anti-ghosting for 26 keys: "Q", "A", "Z", "W", "S", "X", "E", "D", "C", "B", "R", "F", "V", "T", "G", "M", "Space", "↑(UP)", "↓(Down)", "←(Left)", "→(Right)", "Tab", "Alt-L", "Ctrl-L", "Shift-L", "CAPS"

10 Wrist support